

1 Placement Stitch on water solvy stabilizer

2 Tack Down 2-3 layers of flannel and cut as close as possible like an applique

3 3rd step Satin Stitch.

Trim and threads that might stick out through satin.

